



There is a danger of electric shock due to the presence of high voltage (AC240V). Never touch the terminals while the power is on. Make sure to turn off the high voltage AC power supply before commencing wiring work.

**NOTE:** Please read these instructions carefully and keep for future reference. The information in this document is subject to change without notice. For updates please refer to our website.

**NOTE:** Follow the requirements for the installation of the product in accordance with the Specifications. Otherwise it may cause malfunction

**NOTE:** Do not install the product in any location where oil, dust, iron powder, chemicals, or hydrogen sulphide may occur or affect the product. It may cause malfunction.

**This package contains the following items:**

- Main unit: x 1
- EOL resistor: 10k ohm x 3
- Alarm Resistor: 680 ohm x 3
- Jumper: x 1
- Manual: (this document) x 1

**General Description**

The EV-3IO Triple Input/ Output Module with Isolator is an addressable input/output module with short circuit isolator. The module provides three supervised inputs (Class B) and three dry contact relay outputs, 2 are rated at 1A@30Vdc and 1 at 5A@240Vac.

The three inputs are monitored to detect normal/input/open/short state, which can be used as general purpose inputs.

The relay outputs are used for the control of equipment such as dampers and extractors for ventilation or smoke control systems, as well as for shutdown of plants or facilities. The relay contacts are supervised to detect the condition (on /off /relay stuck).

EV-3IO – Triple Input / Output Module with Isolator	EN 54-17: 2005 / AC: 2007 – Short Circuit Isolators EN 54-18: 2005 / AC: 2007 – Input / Output Devices
	<p>For use with Nittan Evolution Protocol Only.</p> <p>Loop Voltage: 20 to 38 Vdc          Quiescent Current: 860µA          Alarm Current: 8.3mA</p> <p>Loop resistance: &lt; 50 ohm/ km          Input line resistance: &lt; 50 ohm/ km          EOL resistor: 10k ohm</p> <p>Input resistance: 470 ohm or 680 ohm          Input threshold level: ON : &lt; 680 ohm,          Short : &lt;50 ohm,          Open : &gt; 20k ohm</p> <p>Relay 1&amp;2 Contact rating: 1A at 30 Vdc          AC Relay Contact rating: 5A at 240Vac          Or 5A at 30 Vdc</p> <p>Min sw open voltage (Vso min): 11 Vdc          Max sw open voltage (Vso max): 14 Vdc          Min sw close voltage (Vsc min): 3 Vdc          Max sw close voltage (Vsc max): 10 Vdc          Max line current (Ic max): 500 mA          Max switching current (Is max): 1500 mA          Max leakage current (Il max): 15 mA          Max switch resistance (Zc max): 150 mΩ          Wire size: Min. 0.75mm<sup>2</sup>          Max. 2.5mm<sup>2</sup></p> <p>Operating temperature: -10°C to 55°C          Storage temperature: -25°C to 65°C          Max. relative humidity: 95%RH, non-condensing          Mass EV-3IO: 475g</p> <p>Technical Data Sheet: TD-EV-3IO</p>
DoP Number: 00641	
	<p>Nittan Europe Ltd. Tel: +44 (0) 1483 769 555          Hipley Street, Fax: +44 (0) 1483 756 686          Old Woking, Email: sales@nittan.co.uk          Surrey, GU22 9LQ Web: www.nittan.co.uk          United Kingdom</p>

**RoHS Compliance Statement**

This product complies with the European Union RoHS (Restriction of Hazardous Substances) directive 2011/65/EU which restricts the use of the following six hazardous materials in the manufacture of electronic and electrical equipment.

- Lead (Pb)
- Hexavalent Chromium
- Mercury (Hg)
- Cadmium (Cd)
- Polybrominated biphenyls (PBB's)
- Polybrominated diphenyl ethers (PBDE's)




Figure 1

### Address Setting

Use EV-AD2-EXT to set the address of the EV-3IO. The factory default address of 1 is given to the module. Connect the EV-AD2-EXT to the address setting port with the Micro USB cable for the programmer and change the address to any of 1-254, with reference to the instruction manual of EV-AD2-EXT programmer. (Note that the number of available addresses can be less depending on a control panel model.) The address can be set regardless of whether power supply from the control panel is turned on or off.

Address setting is possible even after connecting the module to the Loop.

### DIP Switch Operation

With the DIP switch 1, it is possible to select normal mode or failsafe mode of AC relay circuit (5A@240Vac) (refer to Table 1 and Figure 1).

If the loop power supply is off, the relay is activated in the failsafe mode. Refer to Table 2 for the relay position in each condition in the normal/failsafe mode.

The DIP switch 2 can change the input setting (normally-open/ normally-closed) of the Input circuit 1. When the switch is in the off position, the input is set to normally-open in the Input circuit 1. When the switch is in the on position, the input is set to normally-closed in the Input circuit 1.

The switching contacts of Input 2 and 3 are always normally-open, regardless of the DIP switch setting.

Open the cover of the module enclosure, and it is possible to configure the address setting and change the setting of DIP switch or jumper pin (refer to Figure 1).

DIP switch	Position	Function
1	ON	AC Relay: Failsafe mode
	OFF	AC Relay: Normal mode
2	ON	Input circuit 1 Only: Normally closed
	OFF	Input circuit 1, 2 & 3: Normally open

Table 1

Condition	Relay Normal mode	Relay Failsafe mode
Loop power Off	Off	On
Standby	Off	Off
Alarm	On	On

Table 2

### Service and Maintenance

Inspection and tests of the module shall be carried out periodically according to the requirements of BS 5839 Part 1, Fire Detection and Alarm Systems for Buildings: Code of Practice for System Design, Installation and Servicing, or equivalent local codes of practice.

For a routine inspection, ensure the module is secure and undamaged.

When carrying out site testing of the module, set the Fire Alarm Control Panel to test mode and take any necessary precautions, so as to limit the activation of alarm sounders/bells and any fire service summoning device.

### Dimensions




Figure 5

### End of Life Disposal

Like all electronic equipment, at the end of its working life this unit should not be disposed of in a refuse bin. All Nittan products since 2005 have been marked with the WEEE Logo in compliance with European Directive 2012/19/EU and Nittan Europe Limited is a member of a WEEE Compliance Scheme. Contact sales@nittan.co.uk for a copy of our WEEE Compliance Policy.



### Trouble shooting

Problem	Possible cause
No response	The module falls off. Address setting is not correct. Duplicate address. Loop wiring is not correct. An open or short circuit in the loop. Loop voltage is too low.
Communication error	Duplicate address. Loop voltage is too low.
The module information is not found on the panel	Data registered on the control panel is not correct.
Open circuit is detected in the input circuit	Input wiring is not correct. An open circuit in the input circuit. EOL resistor is removed.
Short circuit is detected in the input circuit	Input wiring is shorted.
Input condition is latched	Insulation in the input circuit is not enough. Input wiring is not correct. EOL resistor is not appropriate.
Input is not detected	Input wiring is not correct. Input resistor is not appropriate.
Short circuit is detected in the input condition	Input wiring is not correct. Input resistor is not connected. The DIP switch N.O/N.C setting is not appropriate (DIP switch is set to N.C)
Input is detected in the open circuit condition	The DIP switch N.O/N.C setting is not appropriate (DIP switch is set to N.C)
Relay stuck is detected	Relay is at fault. Relay is welded due to exceeding the rating.
Relay fails to operate while relay stuck is not detected	Loop wiring is not correct. Control panel has incorrect cause and effect programming. There is a problem with Relay.
Relay is activated continuously while relay stuck is not detected	Loop wiring is not correct. There is a problem with Relay.
Relay is activated when powering off the module or the system	The module is set to the failsafe mode
SCI operates	There is a short circuit in the loop. Too many devices (over 20mA in total in a standby condition) are connected between the module and the next SCI.

### LED Operation

The module is equipped with 5 LEDs to indicate the state of the module (refer to Figure 2 and Table 3).

Polling LED: flashes green during polling from the control panel.

Input LED: illuminates red to indicate that an input is activated.

Output LED: illuminates red when the output relay is on after receiving a command from the control panel.

Fault LED: illuminates yellow when a fault condition, i.e. an open or short circuit in the input circuit, or relay stuck fault is detected in the output circuit.

SCI LED: illuminates yellow when a short circuit is detected in the loop and the short circuit isolator (SCI) is activated.





Figure 2

	Colour	Function	State of module	State of LED
<b>Polling LED</b>	Green	Polling	Polling	Flashing
<b>Input LED</b>	Red	Input	Input	Steady on
<b>Output LED</b>	Red	Output	Relay on	Steady on
<b>Fault LED</b>	Yellow	Fault	Open/short (input circuit) Relay stuck (output circuit)	Steady on
<b>SCI LED</b>	Yellow	Loop	SCI	Steady on

Table 3

### Connections



**WARNING**

There is a danger of electric shock due to the presence of high voltage (AC240V). Never touch the terminals while the power is on. Make sure to turn off the high voltage AC power supply before commencing wiring work.

### Installation

**NOTE:** Take care when drilling holes to fit additional cable glands. Remove PCB assembly if necessary to avoid damage.




Figure 4

### General Operation

**Standby condition:** The module receives polling from the control panel at the regular interval.

**Input condition:** When the monitored contact switches into an input state, the module reports the state to the control panel.

**Output Operation:** On a command from the control panel the output relay will change state. It is possible to set the AC relay to "Failsafe" mode, where it will also change state if loop power is lost.

**Fault condition:** The module reports to the control panel on an open or short circuit in the input circuit and relay stuck in output circuit.

**SCI in active condition:** When SCI is activated to isolate a short circuit in the loop, the LED on the module illuminates yellow.

### SCI Function

The EV-3IO has a built-in short circuit isolator. The SCI circuit prevents entire loop failure in the event of a short between L+ and L- on the loop. If a short circuit is detected, the section of line containing a short circuit is automatically isolated. If not required the Isolator can be bypassed using the Jumper provided (refer to Figure 1).